

Tutorial: Resin Moulds

1. At room temp, mix your resin and hardener in a bowl 1:1. This has to be as exact as possible! Mix for about 3 minutes.
2. Within 45 minutes of mixing the resin, pour into your mould. Use something like the tip of a paintbrush to push the resin into the corners.
3. Allow to dry for 24-48 hours.
4. Paint your moulds.
5. Glue your moulds to your furniture using wood glue. Put a piece of tape on top while drying to avoid slipping.
6. Add glaze and you're done!

Brush
with
Brittany

