

Tutorial: Veneer Repair

1. Using the Hot Stuff Instant Glue (medium) and a popsicle stick, glue down any peeling veneer.
2. After holding down the veneer for a few seconds, spray the accelerator.
3. Now that all remaining veneer is attached, it is time to fill any missing veneer. Mix your Minwax Wood Filler (1 drop of hardener for every Tbsp of wood filler).
4. Using a putty knife, quickly apply the wood filler to the missing veneer. Leave it thick for the next step. Let completely dry.
5. Using 220 sandpaper, sand down the wood filler until the piece is smooth and leveled out.
6. Now your furniture is ready to be cleaned and painted!

Brush
with
Brittany

