

Tutorial: Trim Repair

1. Mix the Minwax wood filler (1 drop of hardener for every Tbsp of wood filler)
2. Using a putty knife, quickly apply the wood filler to the broken/missing piece. Leave it thick for the next step. Let completely dry.
3. Using an electric sander and 220 sandpaper, begin sanding the wood filler lightly, guiding the sander along the shape of your trim. Refer to video.
4. Repeat steps 2-3 until desired shape is achieved, cleaning after each sanding.
5. Now your furniture is ready to be cleaned and painted!

Brush
with
Brittany

