

# Tutorial: Replacing Hardware

1. During the prepping stage (after sanding and cleaning), mix the Minwax Wood Filler and Hardener and apply it to the existing holes. Be sure to push the wood filler deep into the holes, leaving enough on top to level out.
2. Let the wood filler dry for 1-2 hours.
3. Once completely dry, use an electric or hand sander to sand off any excess wood filler on the top of the drawer. If you can still see the holes, clean the area and repeat step 2.
4. Clean the drawers with White Lightening.
5. (You can paint your base coat before or after this step.) After choosing new hardware, play around with the placement of them with your design. Once you have found where you want your new hardware to go, measure and mark each one.
6. Using a drill bit that is one size smaller than your new screw, drill each hole. After cleaning once more, your piece is ready for its new design!

