

Tutorial: Adding Legs

1. With your furniture piece upside down, determine where you want your legs to go. Refer to video for tips.
2. Mark where the leg screws will go with a marker.
3. Drill your holes using a drill bit that is smaller than the leg screw.
4. Thread each leg into the drilled holes, ensuring they are exactly where they need to be.
5. Remove each leg.
6. Mix Minwax Wood Filler (1 drop of hardener for every Tbsp of wood filler)
7. Quickly apply wood filler to the bottom of leg, then thread the leg back onto the furniture immediately. Wipe away any wood filler that oozed out when screwing the leg in. Repeat for all legs.
8. Let dry for a couple hours before turning your furniture back over.
9. Now you have a leggy piece of furniture that is ready for cleaning and painting!

